

# **SR Scales®**

by **SR®** Instruments, Inc.

**SRV411i**



**Small Animal Floor Scale**

## **Operating and Service Manual**

---

---

## TABLE OF CONTENTS

<b>PACKING CHECKLIST – Model SRV411i</b> .....	<b>3</b>
<b>ASSEMBLY</b> .....	<b>3</b>
<b>SYSTEM DESCRIPTION and INTENDED USE</b> .....	<b>4</b>
<b>MAINTENANCE and CLEANING</b> .....	<b>5</b>
<b>STORAGE and TRANSPORTATION</b> .....	<b>4</b>
<b>SPECIFICATIONS</b> .....	<b>6</b>
<b>BUTTON FUNCTIONS</b> .....	<b>7</b>
<b>BASIC SYSTEM OPERATION</b> .....	<b>8</b>
<b>THEORY OF OPERATION</b> .....	<b>9</b>
<b>CALIBRATION</b> .....	<b>9</b>
<b>TROUBLESHOOTING</b> .....	<b>13</b>
<b>WARRANTY</b> .....	<b>14</b>
<b>DISPLAY MOUNTING TEMPLATE</b> .....	<b>15</b>

---

---

## TABLE OF FIGURES

<b>Figure 1: SRV411i Button Label</b> .....	<b>7</b>
<b>Figure 2: Calibration Button</b> .....	<b>10</b>
<b>Figure 3: Select and Toggle Button</b> .....	<b>10</b>

---

---

## PACKING CHECKLIST – Model SRV411i Small Animal Floor Scale

√	DESCRIPTION	QUANTITY
	SCALE BASE	1 ea.
	SCALE DISPLAY	1 ea.
	MOUNTING HARDWARE	1 ea.
	AC WALL POWER ADAPTER (UL RECOGNIZED)	1 ea.
	CERTIFICATE OF CALIBRATION	1 ea.
	MANUAL	1 ea.

---

---

## ASSEMBLY

**STEP 1:** Unpack the scale system and check parts against the **PACKING CHECKLIST**. If there are any missing or damaged parts, call the Service Hotline at: 1-800-654-6360.

**STEP 2:** Determine installation location for scale and display, keeping in mind the display cable length is six (6) feet and the display power cord length is four (4) feet. The display may lay flat on a desk or end table. If desired, provisions for wall mount have been incorporated, and can be accomplished in the manner described below.

- A. The display should be installed by qualified personnel. The mounting hardware provided will cover most wall applications.
- B. Determine a position on the wall comfortable to the user. Mark the location of the two (2) mounting holes on the wall (holes are spaced 2.5” on center apart) using the template provided on page 15.
- C. Drill the two (2) pilot holes, no larger than ¼” diameter in the locations marked. Install the two (2) self-drilling screw anchors.
- D. Install the two (2) #8 x 1” flat head screws supplied, leaving approximately ¼” projecting from the wall.

**STEP 3:** Place the SRV411i Small Animal Floor Scale on a flat, hard floor surface. Ensure all four corners of scale are in contact with the floor and scale does not rock.

**NOTE:** Scale should not be placed on carpet or uneven floor surfaces as this may interfere with scale accuracy.

**STEP 4:** Connect the display cable to the scale, then connect the power cable to the display and plug the power adapter into wall power.

---

## SYSTEM DESCRIPTION and INTENDED USE

### SYSTEM DESCRIPTION

The SRV411i Small Animal Floor Scale employs the latest in microprocessor and load cell technology to provide accurate and repeatable weight data. Four (4) identically matched transducers are strategically placed to ensure an accurate representation of the small animal's weight.

The small animal's weight is displayed on a LCD screen. With a push of a button, weight data may be viewed in either pounds or kilograms.

### INTENDED USE

The SRV411i Small Animal Floor Scale is a unique lightweight, low profile stand-on scale system for weighing small animals weighing up to 500 pounds (227 kilograms)



---

## STORAGE and TRANSPORTATION

To maintain proper operation of this instrument, storage and transport conditions should not vary outside the following conditions: Relative Humidity 0% to 85%, Ambient Temperature 14°F to 122°F (-10°C to +50°C).

---

## CLEANING and DISINFECTING

### CLEANING

To clean the display / user interface and other scale contact areas:

- Use soft bristle brush with mild soap and water to clean platform/patient contact areas.
- Wipe surface with clean soft cloth dampened with water and then dry with clean soft cloth
- Do not use abrasive materials to clean scale surface to prevent damage to the surface finish
- Do not spray liquid directly onto scale surfaces. Use only a damp cloth

### DISINFECTION

To disinfect the display / user interface and other scale contact areas:

- Use a soft cloth dampened with disinfectant or a damp disposable disinfectant cloth. Cloth cannot be dripping wet. Follow manufacturer's instruction on the proper use of commercially available disinfectants
- Disinfectant solutions with 1% sodium hypochlorite or 70% isopropyl alcohol are suitable for display / user interface and other scale contact surfaces
- After disinfecting, use a soft cloth dampened with clean water and dry with a soft clean cloth to prevent buildup of material on scale finish
- Do not use abrasive material to disinfect / clean scale surfaces to prevent damage to the surface finish
- Do not spray liquid directly onto scale surfaces. Use only a damp cloth

**WARNING: DO NOT SPRAY CLEANING SOLUTION OR LIQUIDS DIRECTLY ON SURFACES TO BE CLEANED**

**WARNING: EXPOSURE TO EXCESSIVE LIQUID WILL DAMAGE USER INTERFACE KEYPAD**

**WARNING: DO NOT USE PRESSURIZED WATER OR STEAM. THE SCALE SYSTEM CONTAINS ELECTRONIC COMPONENTS THAT MAY BE ADVERSELY AFFECTED BY EXPOSURE TO SUCH AN ENVIRONMENT.**

## SPECIFICATIONS

<b>MAXIMUM WEIGHT CAPACITY</b>	500 lb (227 kg)
<b>DIMENSIONS</b>	Platform: 26.4 in x 18.3 in (67 cm x 47 cm)
<b>DISPLAY TYPE</b>	1" Digit LCD
<b>DISPLAY RESOLUTION</b>	+/- 0.1 lb (0.1 kg)
<b>ACCURACY</b>	0.2% +/- 1 digit of displayed resolution for calibrated range
<b>AUTO ZERO</b>	One button operation
<b>AUTO WEIGH</b>	Scale will automatically turn on and lock in on a stable weight.
<b>AUTO POWER DOWN</b>	After 1 minute
<b>AVERAGING</b>	Automatic digital filter
<b>POWER SUPPLY</b>	AC Wall Power Supply (UL Recognized)
<b>CALIBRATION</b>	Calibration is traceable to NIST
<b>OPERATING CONDITIONS</b>	Normal operating conditions for this product: Ambient Temperature Range: 68°F to 85°F (20°C to 30°C) Relative Humidity Range: 0% to 85% Avoid exposure to high-pressure water or steam.
<b>TRANSPORATION AND STORAGE</b>	Storage conditions should not vary outside the following conditions: Relative Humidity 0% to 85%, Ambient Temperature 14°F to 122°F (-10°C to +50°C)

## BUTTON FUNCTIONS



Figure 1: SRV411i Button Label

### HOLD/RECALL BUTTON

Scale will automatically lock a stable weight that is greater than five pounds and “MEM” will be displayed in the upper left of the display. To manually hold a weight reading at any time during the weighing process, press the “**Hold/Recall**” button. To recall a weight in memory, press the “**Hold/Recall**” button after the display has powered down or with less than five pounds on the scale.

**NOTE:** When the scale is off, pressing any of the buttons will turn on the scale. Press and hold the “**Zero/Weigh**” button to erase the last held weight from memory.

### LB / KG BUTTON

Weight data may be viewed in either pounds or kilograms. Pressing the “**lb/kg**” button allows the operator to toggle between the two readings.

### ZERO / WEIGH BUTTON

The “**Zero/Weigh**” button is used to zero the system before using the scale system. Ensure that nothing is in contact with the weighing surface during this procedure. The display will read “**0.0 Lb**” (or **0.0 kg**).

The “**Zero/Weigh**” button also wakes up the display and shows the weight if it should Auto Power Down before the weighing process is done.

**NOTE:** When system is zeroed, the Hold/Recall memory is erased.

---

## BASIC SYSTEM OPERATION

### SMALL ANIMAL WEIGHING

**STEP 1:** Place scale on hard smooth floor surface to ensure accurate data.

**NOTE:** Avoid carpeting or uneven flooring surfaces.


**STEP 2:** The scale will automatically turn on when weight is detected and lock in on a stable weight.

Alternatively, press the “**Zero/Weigh**” button and wait for the display to indicate “ZERO”. Release the “**Zero/Weigh**” button and the display will read “**0.0**”. Position the small animal on the platform. Weight will be displayed in a few seconds. A stable weight will automatically be stored in memory.

**STEP 3:** To manually hold a weight reading at any time during the weighing process, press the “**Hold/Recall**” button.

**NOTE:** When the scale is off, pressing any of the buttons will turn on the scale. Press and hold the “**Zero/Weigh**” button to erase the last held weight from memory. Only the last stabilized weight will be held in memory.

### SCREEN DISPLAYED SYMBOLS



Scale is zeroed and stabilized

**MEM**

Weight is locked in memory (next stable weight will override memory)



Applied weight load has stabilized



---

## THEORY OF OPERATION

SR Instruments patient weighing systems are digital scales. Strain-gauge force cells convert the force of an applied weight into an analog signal. This signal is amplified by an operational amplifier and converted to a digital signal by analog to digital converter. The digital signal is transferred to a micro-controller where it is filtered, converted to appropriate units, and displayed on a liquid crystal display.

Strain-gauge force cells each contain four strain gauges mounted in a full Whetstone-bridge configuration. These bridges convert the physical movement of the force cell, due to the applied mass on the system, into minute changes in electrical resistance. These changes in resistance produce a voltage difference across the Whetstone-bridge, which is amplified by the operational amplifier.

The output of the operational amplifier is digitized by the analog to digital converter. The converter integrates the analog signal onto the integrating capacitor over a short interval. The integrating capacitor is then discharged at a rate proportional to the reference voltage applied to the converter. The residual voltage on the integrating capacitor is then multiplied by a factor and again discharged at a rate proportional to the reference voltage. The residual voltage from this discharge is again multiplied by a factor and again discharged. The time taken to discharge the capacitor is proportional to the voltage from the operational amplifier, which is proportional to the applied load on the force cells. The time is stored as a binary number in the analog to digital converter and is transferred to the micro-controller when the conversion is complete.

The micro-controller averages and filters the digital output of the analog to digital converter, subtracts the value saved during the system zero operation and scales the filtered output, then displays the result on the liquid crystal display. The micro-controller performs a rolling average of data for continuous weigh and averages the data before locking in on the reading.

---

## CALIBRATION



### IMPORTANT



**CALIBRATION CHECK:** Qualified service personnel only should perform this procedure. Load cells have no user serviceable components and should not be tampered with for any reason. Re-calibration is generally not required, but should be verified periodically to ensure accuracy. The recommendation for calibration check is at least once every 12 months, or as individual maintenance policy requires.



### CAUTION



The integrated circuits and semiconductors on the printed circuit boards may be damaged by electrostatic discharge (ESD). Be sure to use proper handling precautions at all times.

## CALIBRATION (CON'T)




Figure 2: Calibration Button




Figure 3: Select and Toggle Button

### Initial System Setup

When initially set up, calibration is factory set and re-calibration is not needed. The Local Gravitational Acceleration may have to be re-set for the current geographical location for improved accuracy. Automatic Shut Off is shipped with a factory default of 60 seconds. If a longer period of time (up to 900 seconds) is desired, then it will need to be re-set. Both procedures are found below.

### Access System Setup

To access all settings below, break the Calibration Seal. Press the calibration button (Figure 2) using the pointed-end of a pen or similar item. CAL mode is now active.

Refer to Figure 3. The Right Button allows you to toggle through the menus without saving any parameters. The Left Button permits a menu item to be selected or a parameter saved.

**NOTE:** Ensure that nothing is in contact with the scale system during this procedure. Remove hands from the system when noting the displayed calibration results.

---

## CALIBRATION (CON'T)

### Cal Menu

- “**data**” Displays saved calibration and model information.
- “**unit**” Set the available units; lb only, kg only, or selection of lb or kg with mode button.
- “**sec**” Set Auto Power Down Timer between 15 and 900 seconds.
- “**grav**” Set Gravitational Acceleration in  $m/s^2$
- “**Full**” Applied calibrated mass at full scale.
- “**Half**” Used with three point calibration curve. Applied calibrated mass at a second point between zero and full scale, usually at half.
- “**zero**” No calibrated weight applied.
- “**2 pt**” Two-point calibration curve, zero and full scale.
- “**3 pt**” Three-point calibration curve; zero, half and full scale.
- “**save**” Saves the calibration data.
- “**quit**” Quits without saving the calibration data.

### Enter CAL Mode

To enter the CAL mode, press the calibration button (Figure 2) using the pointed-end of a pen or similar item. Toggle through the menu with Right Button (Figure 3). Select or Save data with the Left Button (Figure 3).

### Auto Power Down Timer (Optional)

- a) Toggle through the menu with the Right Button until the display shows “**sec**” then press the Left Button to select.
- b) The display will show four digits <0123>.
- c) Set the desired time in seconds by selecting the first digit and toggling using the Right Button through the digits until desired value is shown. Press the Left Button and continue the same with the remaining digits. The value cannot be less than 15 nor greater than 900.
- d) Press the Left Button and the display will show “**SAVE**”; to save changes, press the Left Button and the display will show “**SAV’d**” or to exit without saving changes, press the Right Button to toggle to “**quit**” and then press the Left Button.

---

## CALIBRATION (CON'T)

### Gravitational Acceleration (Optional)

**NOTE:** Setting the local gravitational acceleration, “**gLOC**”, will not affect the calibration. The local gravitational acceleration, “**gLOC**”, will become the calibrated gravitational acceleration, “**gCAL**” only when it is recalibrated.

- a) While in the CAL mode press the Right Button until the display shows “**grav**” then press the Left Button to select.
- b) The display will show only the four digits to the right of the decimal point <9.XXXX>.
- c) Set the local gravitational acceleration in  $\text{m/s}^2$  by selecting the first digit and toggling using the Right Button through the digits until desired value is shown. Press the Left Button and continue the same with the remaining digits.
- d) Press the Left Button to **SAVE** and the display will show “**SAV’d**” or press the Right Button to toggle to “**quit**” and then press the Left Button to exit without saving changes.

### Full-Scale value

- a) While in the CAL mode press the Right Button until the display shows “**FULL**” then press the Left Button to display default weight.
- b) The display will show only the five digits <XXXX.X> with the thousand-place flashing <1>. Select past to the next digit by pressing the Left Button.
- c) Once in the hundreds-place, set the full scale value (maximum load) by toggling using the Right Button through the digits until desired value is shown. Select the desired value by pressing the Left Button and continue the same with the remaining digits.
- d) Press the Left Button to **SAVE** and the display will show “**SAV’d**” or press the Right Button to toggle to “**quit**” and then press the Left Button to exit without saving changes.

### Half-Scale value

**NOTE:** The Half-Scale value is used only with the three-point calibration. It is a value between zero and the Full Scale values. It is usually close to half of the Full Scale value.

- a) While in the CAL mode press the Right Button until the display shows “**HALF**” then press the Left Button to display default weight.
- b) The display will show only the five digits <XXXX.X> with the thousand-place flashing <1>. Select past to the next digit by pressing the Left Button.
- c) Once in the hundreds-place, set the half scale value by toggling using the Right Button through the digits until desired value is shown. Select the desired value by pressing the Left Button and continue the same with the remaining digits.
- d) Press the Left Button to **SAVE** and the display will show “**SAV’d**” or press the Right Button to toggle to “**quit**” and then press the Left Button to exit without saving changes.

## CALIBRATION (CON'T)

### Calibrate using the Two-Point Calibration Curve; zero and full scale.

- a) While in the CAL mode press the Right Button until the display shows “2Pt” then press the Left Button to display “ZERO”.
- b) With no load applied, “ZERO” the scale by pressing the Left Button when the display shows “zero”.
- c) Display will show “FULL”, apply the predetermined full scale value on the scale and press the Left Button.
- d) Display will show Gravitational Acceleration values. Press the Left button to toggle thru the values.
- e) Display will show “SAVE”, press the Left Button to save and the display will show “SAV’d” or press the Right Button to toggle to “quit” and then press the Left Button to exit without saving changes.
- f) Press the calibration button (Figure 2) using the pointed-end of a pen or similar item to exit CAL mode.
- g) Place a new calibration seal over the calibration button access hole.

**NOTE:** Calibrated weight displayed should be within tolerance as per specifications (see “SPECIFICATIONS” page 6).

## TROUBLESHOOTING

SYMPTOM	REASON/CORRECTIVE ACTION
Weight reading is much lower than expected.	Check that the platform is clean underneath, stand on each of the four corners to see if one corner is not weighing correctly.
System fails to perform correctly.	Check power supply connections. Make sure the scale is clear of any obstacles and that nothing, including the vet, is touching the small animal or scale. Set scale on smooth, hard floor surface.
<b>For additional information or assistance, telephone our Service Hotline: 1-800-654-6360 or e-mail: <a href="mailto:sri@srinstruments.com">sri@srinstruments.com</a></b>	

---

## WARRANTY

### TWO (2) YEAR LIMITED WARRANTY

Each **SR Scales**<sup>®</sup> system is manufactured with high quality components. SR Instruments, Inc. warrants that all new equipment will be free from defects in material or workmanship, under normal use and service, for a period of two (2) years from the date of purchase by the original purchaser. Normal wear and tear, injury by natural forces, user neglect, and purposeful destruction are not covered by this warranty. Warranty service must be performed by the factory or an authorized repair station. Service provided on equipment returned to the factory or authorized repair station includes labor to replace defective parts. Goods returned must be shipped with transportation and/or broker charges prepaid. SR Instruments, Inc.'s obligation is limited to replacement of parts that have been so returned and are disclosed to SR Instruments, Inc.'s satisfaction to be defective. The provisions of this warranty clause are in lieu of all other warranties, expressed or implied, and of all other obligations or liabilities on SR Instruments, Inc.'s part, and it neither assumes nor authorizes any other person to assume for SR Instruments, Inc. any other liabilities in connection with the sale of said articles. In no event shall SR Instruments, Inc. be liable for any subsequent or special damages. Any misuse, improper installation, or tampering, shall void this warranty.

### DAMAGED SHIPMENTS

Title passes to purchaser upon delivery to Transportation Company. Purchaser should file any claims for shortage or damage with the delivery carrier and should refuse any shipment that has obvious external damage.

### RETURN POLICY

All products being returned to SR Instruments, Inc. require a Return Goods Authorization number (RGA). To receive an RGA, call our Customer Service at 716-693-5977 ext 103 or toll-free in the USA and Canada at 800-654-6360 ext 103.

When inquiry is made, please supply model and serial numbers, purchase order and reason for return.

Generally, deleted, damaged, and outdated merchandise will not be accepted for credit. A minimum restocking charge of 15% will be assessed on return of current merchandise unless scale is returned because of SR error.

No returns will be accepted after 30 days.

All returns are to be shipped **FREIGHT PREPAID** to: SR Instruments, Inc., 600 Young Street, Tonawanda, NY 14150.

### RESTOCKING FEE


- **15% fee** will be assessed on return of current merchandise
- **No fees** will be charged if the scale is returned because of an error on the part of SR Instruments, Inc.
- **No returns** accepted after 30 days.

---

## DISPLAY MOUNTING TEMPLATE

Determine installation location for scale and display, keeping in mind the display cable length is six (6) feet and the display power cord length is four (4) feet. The display may lay flat on a desk or end table. If desired, provisions for wall mount have been incorporated, and can be accomplished in the manner described below.

- A. The display should be installed by qualified personnel. The mounting hardware provided will cover most wall applications.
- B. Determine a position on the wall comfortable to the user. Mark the location of the two (2) mounting holes on the wall (holes are spaced 2.5" on center apart) using the template provide below.
- C. Drill the two (2) pilot holes, no larger than ¼" diameter in the locations marked. Install the two (2) self-drilling screw anchors.
- D. Install the two (2) #8 x 1" flat head screws supplied, leaving approximately ¼" projecting from the wall.



# **SR**Scales®

By **SR** Instruments, Inc.

**Precision & Technology in  
Perfect Balance™**